

# Instruction Manual

Model SVRC-BK



SpectraVR 360° Camera and Camcorder



80 Little Falls Road • Fairfield, NJ 07004  
800-631-0868 • Fax: 800-398-1812  
www.HamiltonBuhl.com

## 1. Powering On and Pairing


From your iPhone or Android phone, go to the App Store and download/install the IDV720 App.



1

## Powering On and Pairing (continued)


1. Insert the SD card. Press the power key for 3 seconds to turn the camera on. The blue power light will appear and you will hear two beeps.
2. Click on the Wi-Fi button; the blue Wi-Fi light will flash indicating you are in pairing mode.



2

## Powering On and Pairing (continued)




3. Turn on the Wi-Fi on your smartphone. On the list displayed, find SSID: pano720-XXXX and enter the default password: 88888888. The phone will indicate the Wi-Fi is connected, when successful, and the camera's light will become bright and flash.



3

## Powering On and Pairing (continued)

4. For Android systems, go to the Wi-Fi connection option then press Connect button at the bottom



4

## Powering On and Pairing (continued)

- 1.For iOS Android systems, click the camera icon to connect to SpectraVR 360 Camera. The operations of the SpectraVR 360 camera are the same between iOS and Android.



iOS Android systems




5

## 1.Power On and Connect Camera

From the following interface, operations for Android and IOS systems are almost the same.

On the previewing interface, ① Turnover, ② Rotation, ③ Multi-mode preview display, ④ Setting




zoom screen by gestures, drag the screen to rotate pictures.



6

## 2. Photo and Video Modes


- 1.Click on the Mode Switch button to switch to Photo Mode. The photo light will appear. Click on the Shutter button and the camera will take a photo when the Shutter light flashes once and the buzzer prompts – indicating the photo will be saved on the SD card.
- 2.Click on the Mode Switch button to switch to Video Mode. The Video light will appear. Click on the Shutter button and the camera will begin recording when the Shutter light flashes and the buzzer prompts – click on the Shutter button to stop recording and save the video on the SD card.



7

## 3. Photo and Video Sharing

- How to access Preview Mode
1. Select the Preview Mode to view all contents (SD Card/Camera or Smartphone)
  2. Preview images on the camera
  3. Preview images on your phone
  4. Download or delete photo
  5. Return to camera mode



8

## Photo and Video Sharing (continued)

Select a video or photo to be shared from the Preview Mode, when the interface displays as follows:




Click on the Download icon to download.When download is complete, click on the upper left icon (four window looking icon) to return to the browsing display.Select the Preview Mode to view all contents (SD Card/Camera or Smartphone) document and it will display the following



9

## Photo and Video Sharing (continued)

Click on the Upload icon, and the following screen will show:



START TO SHARE

From this screen, you can set the rotation angles and output quality based on your preference, then click START TO SHARE to send it to others via various different methods.



10



## Product Registration Instructions

- Visit: [www.HamiltonBuhl.com](http://www.HamiltonBuhl.com)
1. Click on Customer Care
  2. Click on Product Registration Icon
  3. Please fill out all fields marked with \* to register

**One-Year Warranty:**  
Warranty begins the date item ships from our warehouse. All products have a one year warranty from original date of shipment, unless otherwise noted.



80 Little Falls Road  
Fairfield, NJ 07004  
1-800-631-0868  
[www.HamiltonBuhl.com](http://www.HamiltonBuhl.com)