

---

## Hamilton Mighty Mic MM3

### Dry Cell operation

All ABS Body, sturdy yet light weight

Built – in Alarm & Microphone

Clear sound, long range & efficient design

Conveniently located Volume Control & Switch

10 Seconds Voice Recording Function

### Product Specifications

Power Output: 10w Rated / 15w Max

Voice Range: 0.5 km

Power Source: 6 x “D” Batteries (Not Included)

Battery Life: 8-10 hrs.

Microphone: Unidirectional

Dimensions: Horn Dia.205mm, Length 340mm

Weight: 1.5 kg without batteries



### Operating Instructions:

1. Open the Back Cover by pressing the Open Button.
2. Insert 6 x “D” batteries then close the back cover until it locks. Now your megaphone is ready for action.
3. To activate the megaphone, press the ON/OFF Button on the Back Cover.
4. When carrying it on the shoulder, Press the ON/OFF button on the megaphone and the button on the hanger inlet to activate.
5. When using the megaphone, place your lips as close as possible to the megaphone or the megaphone on the hanger inlet. Adjust the Volume Control to the desired level without causing any howling or feedback.

### Alarm:

1. Press Alarm button to activate alarm. To switch off the alarm, press the same button again, or press the ON/OFF button.

### Voice Recording and Playback:

1. Adjust the volume control to the minimum position and pull out the hanger inlet before recording.
2. Press the REC button; the indicator light will illuminate and your megaphone is ready for recording.
3. Speak into the microphone to record your message (Maximum recording time 10 seconds)
4. Press the REC button again to complete recording
5. Press the PLAY button to replay your recording. Playback will automatically loop.

### Notes and Precautions

- Ensure correct polarity of Batteries. Insert the batteries in the correct direction by aligning the (–) marks on the batteries with the spring in the back cover.
- When the megaphone is not in use for a long period, remove the batteries to prevent draining.
- Drained batteries will not give sufficient sound volume.
- Replace batteries at regular intervals, for optimum result.

### Product Support

- For technical support, call us at 800-631-0868 or email [techsupport@hamiltonelectronics.com](mailto:techsupport@hamiltonelectronics.com)