

# Hamilton PA-5 Waistband Amplifier Operating Instructions

## Items Included:

- Hamilton PA-5 Waistband Amplifier
- Adjustable Belt (Attached to PA-5)
- Headset Microphone
- Lavalier Microphone
- Carrying Case

## Battery Installation:

- Open the battery door on the rear of the PA-5 and install 6 AA batteries according to the polarity shown on the unit, re-install battery door.
- Be sure to position the red ribbon under the batteries with an end sticking out to make it easier to remove batteries when it's time for replacement.



## Operating Instructions:

- Adjust belt to fit user at waist level and clip the buckle on.
- Insert plug of desired microphone into the MIC socket located next to the POWER/VOLUME knob and position microphone as desired.
- Turn the ON/OFF knob clockwise to turn on the unit and adjust volume to desired level.
- If you experience feedback, reposition microphone or adjust volume as needed.

For technical support visit: [www.HamiltonElectronics.com](http://www.HamiltonElectronics.com)